There may be times when Chromebooks don't work right. You might be able to solve the issue yourself by updating your Chromebooks!

## Step 1

Make sure the Chromebook is connected to OVSD-Secure. If not, you'll need to call x1200. Click **Browse as Guest** in the bottom toolbar.

## Step 2

Click the three dots in the upper right hand corner. Then click **Settings**.

## Step ③

On the left hand side, click the three "sandwich" lines, then click **About Chrome.** 

## Step 4

Chrome OS should begin checking for updates; if not, click **Check for updates**. *If it says it's up to date, and your issue is still not resolved, please submit a ticket at*www.ovsd.org/helpdesk

Otherwise, it will take about 10 minutes, then prompt you to restart the Chromebook.

